

Malfunction Analysis and Troubleshooting

Malfunction	Analysis	Troubleshooting
All indicator lights in red or no light, unable to start.	Ran out of battery.	Charge it for 3 to 5 hours to make sure that it gets a full charge.
All indicator lights flicker in red and green alternately, unable to start.	The jar is not tighten to the base.	Tighten the jar and base, make sure the magnet is aligned with the power button.
Stop working, all indicator lights flicker in red for 8 seconds.	Ingredient is too thick or volume too big, motor overload protection.	Add some liquid or cut ingredients into smaller pieces or shift into Pulse Mode, then restart it.
Leakage.	The seal is not placed properly; jar/cap is cross-threaded.	Check seals; check thread alignment when screwing on jar/cap.

Like & Follow On:
[Facebook.com/BottleRocketBlenders](https://www.facebook.com/BottleRocketBlenders)

Shop, Share & Review On:
[Amazon.com/Shops/Bottlerocketblenders](https://www.amazon.com/Shops/Bottlerocketblenders)

NOTE :

- Product is suitable for USB Type-C cable. Suitable for power bank charging as well.
- When not used for a long time, charge it fully to keep battery in high voltage state in order to prevent damage.



Don't put it in the dishwasher



Keep Away From Fire



Non-microwavable



Fragile



Food Contact Compliance

Cautions

- DO NOT remove the lid or add in something rigid in your blender when it is blending.
- DO NOT submerge the base into water to prevent base elements from damaging and make sure it is off before cleaning.
- DO NOT disinfect your blender in microwave or hot water above 80°C.
- DO NOT put your blender in freezer.
- DO NOT clean your blender with any kind of metallic spiral ball to prevent parts from scratching or damaging.
- DO NOT clean your blender with a dishwasher machine.
- DO NOT charge your blender when it is wet.
- DO NOT repair or disassemble it by yourself otherwise your warranty will be void. If malfunction occurred, kindly contact us.

The USB-C port is waterproof, but do not soak the base in water or put it into the dishwasher for cleaning. This will damage the unit and VOID the Warranty!



!!!WARNING!!!
KEEP OUT OF
REACH
OF CHILDREN



Step 1
Cut fruits into small pieces before adding into the blender to fill up about 60% of the jar capacity.



Step 2
Add some drinkable liquid until it reaches 80% of jar capacity.



Step 3
Tighten the lid and tilt down the blender to make sure fruit pieces are not stuck under the blades.



Step 4
Blend Mode: Click once power button to start blending and green lights flashing. Slightly tilt it back and forth while blending if desired. Click once again to pause. **Pulse Mode:** Double-click power button to enter into pulse mode. While yellow lights flicker, press and hold the power button repeatedly to pulse. Pulse mode will automatically end after 5S of inactivity and yellow lights off.

PORTABLE BLENDER
Imported Environmental-friendly Materials
CE, ROHS, FCC Approval



BOTTLE ROCKET™

**VETERAN OWNED
AND OPERATED**



Check Battery Level (The last second of LED light color displays battery capacity under Blend Mode)

1%- 17% : no lights
 18%-33% : 2 green lights on
 34%-50% : 4 green lights on
 51%-67% : 6 green lights on
 68%-83% : 8 green lights on
 84%-99% : 10 green lights on
 Fully charged, all green lights on, red light off

Nutrition Is The Mission!™

Model :	BRv3
Jar Capacity :	600ml
Jar Material :	AS
Base Material :	ABS
Blade Material :	304 Stainless Steel
Blending Voltage :	7.4V
Charging Voltage / Current :	5V / 1A
Battery Type / Capacity :	18650 / 2000mAh*2
Motor Speed :	18000rpm
Charging Time :	About 3 to 5 hours
Single blend time of Blend mode:	30 seconds a cycle
Maximum blend time of Pulse mode:	30 seconds

"JUST BOTTLE ROCK IT!!!"™

Warranty

We offer 12 months warranty on all our products for fault or product quality. Accidental damage or damage as a result of misuse is not covered under this warranty.

Bottlerocketblenders@gmail.com